




## Crevasss Rescue v9













- Grace builds an initial anchor with a picket planted in the snow.
- She connects the weighted rope to the anchor using a prusik hitch.
- Brooke slowly transfers weight to the anchor.
- Brooke moves down but still keeps in self arrest position.




## **Tips**


- If no picket is available, use an ice axe for the initial anchor.
- A vertical placement is weak. Brooke should be ready to self arrest any time. She should also guard the initial anchor by standing on it in the following steps whenever possible.
- When clipping the prusik to the anchor, keep the hinge of the biner gate (the white dot in the diagram) close to the prusik.
- Push the prusik as far as possible before Brooke gets up to minimize the slip in the weight transfer.






- Grace connects the second anchor to both the prusik holding the weight and the first pulley.
- Brooke eases up, clips her personal anchor into the second anchor, and unties from the rope.
- Grace goes down to the edge of the crevasse prusiking on the rope as protection.
- Keep the angle between two anchors small to better equalize them.
- Keep the webbing on the second anchor as tight as possible. It's easier if you attach everything to the system, stretch it out, and measure backwards before digging.
- When clipping the second anchor, keep the hinge of the biner gate close to the prusik.
- Check if both anchors are connected to the system symetrically.







Published by Google Drive – Report Abuse – Updated automatically every 5 minutes