


Z- Pulley

Leave in figure-8 when you go to check on the fallen climber. Untie figure-8 when ready to pull rope to raise fallen climber. Prusiks will pull closer to each other and you will need to reset the z-pulley. Re-tie the backup figure-8 and pull the prusik back toward the crevasse lip to reset.



1. Check with Climber B to make sure they can hold fallen Climber A
2. Work your way to Climber B, probing for crevasses as you go
3. Build initial anchor (vertical picket) about 5 - 10 feet toward fallen Climber A.
4. Attach Bachmann to rope between Climber A and B. Run perlon sling from the Bachmann to the locker of the anchor.
5. Guard anchor as Climber B slowly gets up and transfers weight to anchor.
6. Swap guarding with Climber B, Climber B personals in to anchor. **(REVERSE THESE! B personals in first.)**
7. Attach pulley to rope above Bachmann with a non-locker. Tie backup figure-8 and clip it to this non-locker.
8. Clip this non-locker through the locker of the anchor.
9. Build a deadman anchor. Attach this anchor to the perlon sling with a locker. Climber B attaches personal to both anchors, and unties from rope.
10. Take gear from Climber B, go check on fallen Climber A. Pad lip of crevasse with your ax.
11. Attach prusik on the taut rope about 4-6 feet from crevasse edge.
12. Attach second pulley on rope between you and the anchor, and attach to other end of prusik sling.
13. Go back to anchor, personal in, untie backup figure-8 and pull with Climber B.